BATTERY SPRAYER SERIES



Table of Contents

1. Overview 1
2. Structure and Features 1
3. Technical parameters 2
4. Operating Instructions 3
5. Notes 4
6. Troubleshooting 4
7. Structural diagram and statistics table 5
8. Packing List 6

Thank you for purchasing our Power Sprayer.You are required to familiar yourself with this Manual so as to operate and maintain this Sprayer properly.

1. Overview

Battery Series Sprayer is Extremely Ergonomic, so as easy to Use, useful and **Assembly to Maintain** any and **High Efficiency** sprayer **Integrating Processes. Keep** with **Chinese culture and characteristic ultra efficiency, eco-friendly design appropriate** to **Chinese agricultural production practices.** Battery Series Sprayer **is designed to** please **your life, combined, and applies controlling of tension and safety.** Series **is one** of **the most advanced sprayers in the world.** Battery Series Sprayer **is designed to** be **extra** in **significantly labor saving and simple as efficiency.For a three-zone field** with **a square shape, the operation time is reduced by more than 50% Only Spend** after use, **Will undergo 24hrs immersion with 5-10%of disinfectant,**

To use when rainfall atomization result.

2. Structure and Features

Overview: The sprayer consists of a barrel, a frame, a motor, a pump, a charger, a battery, a pressure control valve, a lance, a spraying rod, nozzle, a duty conversion knob, a spraying rod and other accessories.

Smooth and reasonable appearance: The barrel is ergonomically designed to reduce the load of human bodies when using spraying.

Lever valve, a wide diaphragm pump which is of compact size, high weight, high pressure and excellent stress.Over-flow spraying, pressure protection control to ensure consistent spraying pressure.

Multi-angle nozzle,pressure to prevent foreign matter in particles from clogging.Be able to adjust the angle of the nozzle,convenient to operate and meet different needs.

Solid water-voltage short circuit, to use of prolonged operation, the alarm will be heard when the voltage of lower dimension of 21V+, as an protect the battery. The explosion-proof design of the battery, to avoid the battery explosion in the event of a short circuit.

Have a special charger: Chinese intelligent three-section charging,Constant current, constant voltage, trickle charge, to ensure the battery charging safety and convenient practices. The without lamps of charger Three Charging Current Ranges(Charging, Full, Fault).

3. Technical Parameters

Name	Battery Sprayer
Tank capacity	16 kg
Battery	12V/8Ah Lithium battery
Charger	Input: 100-240V/50-60Hz; Output: 12.6V/2A
Motor	Brushless DC motor, 12V, 120W
Pump	Diaphragm pump, 1.2MPa
Nozzle	Adjustable nozzle
Net weight	8.5 kg
Gross weight	11.5 kg
Max. Pressure	0.35MPa

4. Operating Instructions



Remind: Before use, make sure the battery is fully charged. Before charging, make sure the charger is connected to the power supply. Do not charge in the rain or in a humid environment. Do not charge in a high temperature environment. Do not charge for more than 12 hours.



Do not use to charge lead-acid batteries.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Charging Current Ranges(Charging, Full, Fault).

Charging, Full, Fault. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

5. Notes

The battery has been charged before being delivered. Discharge it until self-discharge to the normal temperature and storage. Additional charging before initial use time is required.

Do not use the sprayer when the battery is low power. Otherwise, it will damage the diaphragm. Please select the sprayer and the nozzle that meet the needs to be sprayed.

Do not use the sprayer when the battery is low power. Otherwise, it will damage the diaphragm. Please select the sprayer and the nozzle that meet the needs to be sprayed.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not charge the battery in a flammable environment. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

Do not use to charge lead-acid batteries. Do not charge the battery in a high temperature environment. Do not charge the battery for more than 12 hours.

6. Troubleshooting

Problem	Cause	Solution
The motor turns on but the pump does not work	The water valve is open and the pump is not primed	Close the water valve and prime the pump
	The pump cannot be primed	Check if the pump is damaged and replace it if necessary
The motor turns on but the pump does not work	The battery is low	Charge the battery
	The switch is damaged	Replace the switch
	The motor is damaged	Replace the motor
The pump is primed but the pressure is low	The spraying rod or nozzle is clogged	Remove the spraying rod or nozzle and clean it
	The pressure relief valve is damaged	Replace the pressure relief valve
	The pump is damaged	Replace the pump
The pump is primed but the pressure is low	The spraying rod or nozzle is clogged	Remove the spraying rod or nozzle and clean it
	The pressure relief valve is damaged	Replace the pressure relief valve
	The pump is damaged	Replace the pump

Store sprayer with cool spot in liquid or strong acid, strong base and flammable goods. Avoid storing in the environment that exist particulate dirt like assembling purpose or vegetables. Total time **no salt solid at once.**

The salt shall be cleaned thoroughly after each use so as to avoid corrosion clogging and rusting. Remove the battery from the sprayer and charge it in a dry and well-ventilated place. Do not charge near. Do not store a unit with a dampened cloth. Dry exterior of unit and sprayer of water, and water before storing at the place of discharge.

Do not store the sprayer in a humid place or exposed to the sun. In case of long-term storage, regular full discharging and recharging will be carried out half a month, a month or two months at a time to prevent the battery from being damaged by deep discharge.

Don't operate the Sprayer at a place with a temperature exceeding 40 . or lower than 10 .

Prior to spraying, Check the connection between the hose and check whether the valve is closed. If the pump is primed, open the valve.

Be sure to switch off the power before repair.

Do not use the sprayer to spray the liquid that may damage the plastic or rubber parts.

Do not store the sprayer in the sun for long periods of time.

Never spray powders or particles with the Sprayer.

Unauthorized reworking of the sprayer is strictly prohibited.

7. Structural diagram and statistics table



8. Packing List

No.	Description	Qty. (pcs)	Remarks
1	Main unit of Sprayer	1	**Additional parts including** expansion tube, spray rod and nozzle are available for **optional purchase.**
2	Battery	1	
3	Power cord	1	
4	Operating instructions	1	
5	Certificate of qualification	1	
6	Assembly accessories	1	
7	Assembly tool kit(s)	1	
8	Charger	1	
9	Hose for spraying	1	
10	Warranty card	1	
11	Packing List and Inspection	1	

Structural diagram and statistics table



Structural diagram and statistics table



Structural diagram and statistics table



Structural diagram and statistics table